

# Web Camera and Headset Quick Start Guide


## Web Camera

1. Open your Web browser and navigate to [www.comotivsystems.com](http://www.comotivsystems.com).
2. Click the **Support** button.
3. Click the **Documents** button.
4. Under the Comotiv Connect Documentation heading, click **Creative Webcam Driver**.
5. Save and run the driver file.

- \* If you are using Internet Explorer, in the popup box click Save then choose a location to save the file to. Next, locate the downloaded file and double-click it.


If you are using Firefox, in the popup box click Save File. Next, locate the downloaded file and double-click it.

6. Click Yes.
7. Click Next.
8. Click Next.
9. Connect the Web camera to your computer's USB port.



## Headset

10. Plug the headset's pink microphone connector into the microphone jack of your computer.
11. Plug the headset's black headphone connector into the speaker/headphone jack of your computer.

- \*  Make sure that the headset's control switch indicates that the microphone is activated.